



SKYSPAN SHADE
COMMERCIAL UMBRELLAS AND SHADE STRUCTURES



Alfresco Portable
Umbrella Replacement
Canopy

Method Statement

1. Retract umbrella completely.
2. Remove bolts from end of arms to release canopy.
3. Remove screw and washers from the centre of the canopy.
4. Slide canopy over top of umbrella to remove.
5. Slide new canopy into position with smoother side facing up.
6. Replace screw and washers in centre of the canopy.
7. Attach canopy by connecting canopy corner plates to end of arms ensuring that the stainless cable is between the bolt and the corner plate as per the photo below.



8. Partially wind umbrella up while supporting all arms and checking cable within corner plate, canopy position, centering and alignment of arms with associated seams. Continue to wind until canopy is reasonably taut.
9. Thoroughly inspect positioning of canopy and cable.

SKYSPAN SHADE
Office / Factory Unit 1, 4 Old Pacific Highway, Yatala, Queensland 4207, Australia
Tel: +61 (0) 7 3804 6288 Email: sales@skyspanshade.com.au
www.skyspanshade.com.au