SKYSPANSHADE

COMMERCIAL UMBRELLAS AND SHADE STRUCTURES

Centre Column Lighting

Method Statement

Method

12 Volt Low Level Lights

To be installed by a qualified electrician only.

Screw plastic light fittings to arm in the desired position. Drill through centre hole on the light fitting and run a 12 volt cable down the extruded channel in the top of the arm and connect to the cable that Skyspan has pre-installed at the top of the column. NB: This is not a pull cable and cannot be removed.

A 12 volt transformer can be attached at the electric/source power board.

An earth point is under the umbrella base and can be accessed before installation, when umbrella is connected to the mains feed.