SKYSPANSHADE
COMMERCIAL UMBRELLAS AND SHADE STRUCTURES

Horizon Installation Jack

Centre Column Umbrella

Method Statement

Installation Jack

Depending on the column size and umbrella type you may need to alter the travel using the supplied jacking column spacers to achieve desired jacking height. This is a 2 person installation.

Required Tools

1. Skyspan umbrella hex drive winding handle
2. Securing strap

Method

1. Install umbrella as per supplied method statement.

2. Apply padding to top of installation jack.

3. Place the Installation Jack foot in the bolt holes of the umbrella.

4. Carefully feed the jack in under the canopy and place on the foot. Wind the jack up to the top plate so that it can free stand.

5. Secure the Installation Jack with a strap around the main column of the umbrella.

6. Once secured, wind the jack and this will push the jacking column on the umbrella up and the arms and canopy will start to open. When the umbrella is wound up enough, use a ladder to gain a visual on the jacking column of the umbrella. While the other person continues to wind the umbrella up, keep winding until the retention bolt hole on the jacking column is visible.

7. Keep winding up until the retention hole in the jacking column is visible and insert and fix off the retention bolt, You can now relieve the tension on the chain block and remove external jacking kit.

SKYSPAN SHADE
Office / Factory Unit 1, 4 Old Pacific Highway, Yatala, Queensland 4207, Australia
Tel: +61 (0) 7 3804 6288 Email: sales@skyspanshade.com.au
www.skyspanshade.com.au