



SKYSPAN SHADE
COMMERCIAL UMBRELLAS AND SHADE STRUCTURES



Sunset Umbrella Replacement Canopy

Method Statement

1. Retract umbrella completely.
2. Remove arm end bolts.
3. Remove dome cap, nut and clamp plate.
4. Slide canopy over top of umbrella to remove.
5. Slide new canopy with smoother side facing up over top plate placing hole at the centre of the canopy over M8 stud.
6. Attach canopy by connecting canopy corner plates to end of arms ensuring that the stainless cable is between the bolt and the corner plate as per the photo below.



7. Partially wind umbrella up while supporting all arms and checking cable within corner plate, canopy position, centering and alignment of arms with associated seams. Continue to wind until canopy is reasonably taut.
8. Thoroughly inspect positioning of canopy and cable.
9. Retract umbrella completely and put back in place clamp plate, dome cap and nut to complete installation.

SKYSPAN SHADE

Office / Factory Unit 1, 4 Old Pacific Highway, Yatala, Queensland 4207, Australia

Tel: +61 (0) 7 3804 6288 Email: sales@skyspanshade.com.au

www.skyspanshade.com.au