SKYSPANSHADE
COMMERCIAL UMBRELLAS AND SHADE STRUCTURES

Typhoon Installation Jack

Centre Column Umbrella

Method Statement

Installation Jack

Depending on the column size and umbrella type you may need to alter the travel using the supplied jacking column spacers to achieve desired jacking height. This is a 2 person installation.

Required Tools

1. Installation jack
2. Skyspan umbrella hex drive winding handle
3. Securing strap
4. Installation jack foot

Method

1. Install umbrella as per supplied method statement.

2. Place the Installation Jack foot in the bolt holes of the umbrella base.

3. Carefully feed the jack in under the canopy and seat on the foot and wind the jack up to the top plate so that it can free stand and apply padding if necessary.

4. Secure the Installation Jack with a strap around the main column of the umbrella.

5. Once secured, wind the jack and this will push the jacking column on the umbrella up and the arms and canopy will start to open. When the umbrella is wound up enough, use a ladder to gain a visual on the jacking column of the umbrella, while the other person continues to wind the umbrella up.

6. Keep winding up until the retention hole in the jacking column is visible and insert and fix off the retention bolt, you can now wind the jack down and remove external jacking kit.