SKYSPANSHADE
COMMERCIAL UMBRELLAS AND SHADE STRUCTURES

# VISTA - Installation Jack

## Cantilevered Umbrella

Method Statement

# Installation Jack

## Required Tools

1. Skyspan umbrella hex drive winding handle

## Method

1. Unpack vista head unit and leave laying on it's side with the supplied half-moon foam packer supporting the head unit.

2. Take umbrella strap off and un-ravel the canopy.

3. Carefully slide the vista installation jack in through the foam arm spacer and seat the head of the installation jack on the base of the vista head unit mast. Make sure to align the two button head bolts of the vista mast with slot on the head of the jacking unit and the installation jack column resting inside of the arm spacer.

4. With the umbrella still laying on the half-moon foam packers make sure all arms are slotted into the arm spacer and wrap the canopy back around the arms and secure the strap around the head unit.

5. Stand the head unit upright and shift into place and wind the jack whilst guiding the head unit to the mounting plate on the head unit.

Follow the Vista installation method statement to complete the Vista umbrella installation.

**Depending on the column size and umbrella type you may need to alter the travel using the supplied jacking column spacers to achieve desired jacking height.**